

DUMPSQUEEN

HCS-5G RAN V1.0

Huawei H35-460

Version Demo

Total Demo Questions: 15

Total Premium Questions: 218

Buy Premium PDF

<https://dumpsqueen.com>

support@dumpsqueen.com

dumpsqueen.com

QUESTION NO: 1

After the 5G network UE is powered on and enters the idle state, what operations will be performed in the Attach process? (Multiple Choice)

- A. Establish the same mobility context between UE and corenet
- B. Through the EPS ATTACH process, UE can also obtain network-assigned IP addresses
- C. Establish default hosting between UE and the core network
- D. Listen on the network to get downstream synchronization

ANSWER: A B C

QUESTION NO: 2

To enable data distribution with NR base stations in NSA networks, you need to configure the default bearer mode of NSA DC to SCG_SPLIT_BEARER on the NR side

- A. Correct
- B. Errors

ANSWER: B

QUESTION NO: 3

In order to verify the successful establishment of NSA services, which of the following items need to be checked?

- A. Whether LTE can ping NR
- B. Whether the NR S1-C status is normal
- C. Whether the NR S1-U status is normal
- D. X2 link status

ANSWER: B C D

QUESTION NO: 4

After the new NSA network is turned on, which of the following phenomena can be observed?

- A. eNodeB sends SGNB_ADD_REQ through the X2 interface

- B. The UE sends RRC_CONN_RECFG_COMP messages to the NR base station
- C. You can observe the RRC_MEAS_RPRT messages reported by UE
- D. The base station can be observed sending RRC_CONN_RECFG message to the UE, carrying the EventB1 cell

ANSWER: A C D

QUESTION NO: 5

Which of the following requirements is generally included in the target rate of urban areas in eMBB scenarios of 5G?

- A. 10Gbps peak rate
- B. 100-200Mbps continuous coverage
- C. Target rate of 500Mbps
- D. 100Mbps continuous coverage

ANSWER: A C D

QUESTION NO: 6

What information does UE carry in reporting the MR of the NR neighbourhood?

- A. THIS
- B. RSRP
- C. MAC CE
- D. PCI

ANSWER: B

QUESTION NO: 7

When NSA selects and interprets the 2.6Ghz band networking, the uplink and downlink decoupling scheme can not be used.

- A. Correct
- B. Errors

ANSWER: A

QUESTION NO: 8

Which of the following protocols/data falls under Tier 3?

- A. MAC protocol
- B. IP data
- C. RLC protocol
- D. RRC protocol

ANSWER: B D

QUESTION NO: 9

What is the application type used for gNodeB remote maintenance channel detection?

- A. TCP
- B. PING
- C. UDP
- D. ARQ

ANSWER: B

QUESTION NO: 10

Which module is used in the base station power system to monitor the power environment?

- A. BDU
- B. PSUs
- C. ATS
- D. PMU

ANSWER: D

QUESTION NO: 11

gNodeB must configure transmission data before you can configure wireless data.

- A. True
- B. False

ANSWER: B

QUESTION NO: 12

Which of the following boards cannot be reset by command?

- A. FAN
- B. UPEU
- C. UMPT
- D. UBBP

ANSWER: A B

QUESTION NO: 13

When gNodeB adds NR RF unit AAU, which item should be selected for its "RF unit working standard"?

- A. LTE_TDD_NR
- B. NR_Only
- C. LTE_FDD_NR
- D. DNBIOT_NR

ANSWER: B

QUESTION NO: 14

Which of the following is the default near-end maintenance address for gNB UMP boards?

- A. 192.168.211.158
- B. 192.168.0.59
- C. 192.168.211.159
- D. 192.168.0.49

ANSWER: D

QUESTION NO: 15

Which of the following two cells has a large interference from PBCH?

- A. PCI0 and PCI3
- B. PCI0 and PCI1
- C. PCI0 and PCI4
- D. PCI0 and PCI2

ANSWER: C